



Board & Batten on 20 mm Cavity - Roof to Wall Junction


Scale 1:3 @ A4



Board & Batten on 20 mm Cavity - Base of Wall - Concrete


Scale 1:3 @ A4






Board & Batten on 20 mm Cavity - Aluminium Joinery Sill


Scale 1:3 @ A4



Board & Batten on 20 mm Cavity - Aluminium Joinery Jamb


Scale 1:3 @ A4






Board & Batten on 20 mm Cavity - Soffit - Eaves Mould

Scale 1:3 @ A4



Board & Batten on 20 mm Cavity - Soffit - Batten


Scale 1:3 @ A4






Board & Batten on 20 mm Cavity - Roof to Wall Junction

Scale 1:3 @ A4




Board & Batten on 20 mm Cavity - Internal Corner

Scale 1:3 @ A4




Board & Batten on 20mm Cavity - External Corner

Scale 1:3 @ A4



Board & Batten on 20mm Cavity - Fixing Detail

Scale 1:3 @ A4



Board & Batten cladding should be installed as per the current building code. Please refer to BRANZ bulletin 468, Fixing of Timber Weatherboards. See E2/AS1 for a complete list of fixing options.

Vertical Board and Batten cladding must be in continuous lengths over a story height.

Board & Batten on 20 mm Cavity - Horizontal Joint

Scale 1:3 @ A4

